Setting Up Epson EB-L260F, 725Wi Projector

1200 August 18, 2023 Projectors 1606

Select the correct orientation. Select the numbers on screen that are projected correctly

Select "English" for the language



Setting up mirroring
Press the "Menu" button on the remote
Select "Network" from the menu on the left side, then select "Network Settings" from the menu on the right side
If you want the projector to have a specific name select "Projector Name" to change its name
Select "Priority Control Interface"

Select	"Wireless LAN", then select "Return"
Select	"Simple AP"
Select	" On ", then select " Return "
Select	"Network Projection"

Select "Projector Keyword"
Select " On ", then Select " Return "
Select "Epson iProjection"
Select " Off ", then select " Return "

Ensure "Screen Mirroring" is On and the options below it look the same as the image below
Select "Interrupt Connection" under Screen Mirroring
Select "Off", then select "Return"



Select "Return"
Select "Set"
You will be prompted to save the network settings. Select "Yes"
You will be taken back to the main settings menu. You can exit this menu at any time
Sharing Screen
Press the Home button on the remote
At the home screen the projector name and keyword will be displayed at the top of the screen. This will

be needed when attempting to connect to the projector.
More instruction can be seen if you select "Screen Mirroring1" or "Screen Mirroring2" from the home screen

Note : Casting can be started on Windows laptops by pressing the Win + K on your keyboard. A sideba will appear & the display should appear on the list.
Online URL: https://kb.lawrence.k12.ma.us/article.php?id=1200